

by Schneider Electric

IDPIUS 902/961/971/974





CONTENTS

IDPlus 902/961 USER INTERFACE (KEYS AND LEDS)	4
IDPlus 971/974 USER INTERFACE (KEYS AND LEDS)	6
IDPlus 902/961 CONNECTIONS	8
IDPlus 902/961 APPLICATIONS	9
IDPlus 971 CONNECTIONS	10
IDPlus 971 APPLICATIONS	11
IDPlus 974 CONNECTIONS	12
IDPlus 974 APPLICATIONS	13
LOADING DEFAULT APPLICATIONS	14
SETPOINT MODIFICATION LOCK	14
INSTRUMENT ON/OFF	14
ACCESSING AND USING THE MENUS	14
MANUAL DEFROST CYCLE ACTIVATION	15
MECHANICAL INSTALLATION - DIMENSIONS	15
TROUBLESHOOTING	15
ALARMS	16
PASSWORDS	18
USING THE COPYCARD	18
MACHINE STATUS MENU	19
PROGRAMMING MENU	19
MAX/MIN TEMPERATURE ALARMS	20
LIABILITY AND RESIDUAL RISKS	20
DISCLAIMER	21
ELECTRICAL CONNECTIONS	21

EN

21
22
22
24
25
26
30
31
32
37
38
39

IDPlus 902/961 USER INTERFACE



IDPlus 902/961

KEYS						
UP Press and release Scroll menu items Increases values Press for at least 5 sec Activates the Manual Defrost function	0	STANDBY (ESC) Press and release Returns to the previous menu level Confirms parameter value Press for at least 5 sec Activates the Standby function (when outside the menus)				
DOWN Press and release Scroll menu items Decrease values Press for at least 5 sec Function can be configured by the user (par. H32)	set	SET (ENTER) Press and release Displays alarms (if active) Opens Machine Status menu Press for at least 5 sec Opens Programming menu Confirm commands				

		4	EDs				
	Reduced SET / Flashing: Quick flashing: Off:	Economy LED economy Setpoint active access to level2 parameters otherwise	((t=1))	Alarm LED Permanently on: Flashing: Off:	alarm active alarm acknowledged otherwise		
₩	Compressor LI Permanently on: Flashing: Off:	ED compressor active a delay, a protection or a locked start-up otherwise	**	Defrost LED Permanently on: Flashing: Off:	defrost active manual or D.l. activation otherwise		
1	HEAT status LE Permanently on: Off:	D compressor in HEAT otherwise	2	Status Led Flashing: Off:	manual or D.I. activation of Deep Cooling otherwise		
°C	° C LED Permanently on: Off:	°C setting (dro = 0) otherwise	°F	° F LED Permanently on: Off:	°F setting (dro = 1) otherwise		
* To activate the LOC function: - enter the "Basic Commands" menu by pressing the key set. - press keys (①) and (会) within 2 seconds.							
If the LOC function is Active and you try to enter the "Programming" menu, the text LOC appears. If this happens, the parameters are still displayed but cannot be edited. To disable the keypad lock, repeat the aforementioned procedure.							
* When s all fund	witched on, the d tion correctly.	evice performs a Lamp Test; the d	isplay and I	LEDs will flash for	several seconds to check that they		

IDPlus 971/974 USER INTERFACE



IDPlus 971/974

	KEYS						
8	UP Press and release Scroll menu items Increases values Press for at least 5 sec Activates the Manual Defrost function	0	Standby (ESC) Press and release Returns to the previous menu level Confirms parameter value Press for at least 5 sec Activates the Standby function (when outside the menus)				
8	DOWN Press and release Scroll menu items Decrease values Press for at least 5 sec Function can be configured by the user (par.H32)	set	SET (ENTER) Press and release Displays alarms (if active) Opens Machine Status menu Press for at least 5 sec Opens Programming menu Confirm commands				

	LEDs							
	Reduced SET / Flashing: Quick flashing: Off:	Economy LED economy Setpoint active access to level2 parameters otherwise	((t=1))	Alarm LED Permanently on: Flashing: Off:	alarm active alarm acknowledged otherwise			
₩	Compressor LE Permanently on: con Flashing: Off:	D pressor active a delay, a protection or a locked start-up otherwise	*	Defrost LED Permanently on: de Flashing: Off:	frost active manual or D.I. activation otherwise			
×	Fans LED Permanently on: Off:	fans active otherwise	AUX	Aux LED Permanently on: Flashing:	Aux output active manual or D.I. activation of Deep Cooling			
°C	° C LED Permanently on: °C s Off:	setting (dro =0) otherwise	°F	° F LED Permanently on: °F Off:	setting (dro =1) otherwise			
* To activate the LOC function: - enter the "Basic Commands" menu by pressing the key set. - press keys () and () within 2 seconds.								
If the LOC function is Active and you try to enter the "Programming" menu, the text LOC appears. If this happens, the parameters are still displayed but cannot be edited. To disable the keypad lock, repeat the aforementioned procedure.								
* When s all fund	witched on, the d	evice performs a Lamp Test; the di	splay and L	EDs will flash for	several seconds to check that they			



IDPlus	902: TERMINALS	IDPlu	s 961: TERMINALS
OUT1	OUT1 relay	*	1-2: Compressor relay
Supply	6-7: models 12 Vac/dc or 3-4: models 230 Vac	Suppl	6-7: models 12 Vac/dc or 3-4: models 230 Vac
N-L	230 Vac power supply	N-L	230 Vac power supply
10-9	Probe Pb1	10-9	Probe Pb1
10-11	Digital Input 1/ Pb3 probe	10-11	Digital Input 1/ Pb3 probe
ΠL	TTL Input	TTL	TTLInput

Application setting	s				AP1&AP2
F = Functions H = Inputs and Outputs R = Relay Output	AP1	AP2	AP3	AP4	
Cold application	Х	Х		Х	₩ ⁷ Ambient
Hot application			Х		
F - Timed defrost	Х			Х	↓ <u>↓</u> ↓
F - Alarm on Pb1	Х	Х	Х	Х	
F - Overheating				Х	
H - Pb1 present	Х	Х	Х	Х	Valve Evaporator Compressor
H - Pb3 / D.I.1 enabled				Pb3	
R - Compressor/Filling	Х	Х		Х	AP4
R - Heating elements			Х		Q RETETER Q
					o initiali o
AP3	Pb1 Ambier	ıt			
Ambient = Ambient	+				Evaporator Compressor
Evaporator = Evaporator					Compressor = Compressor TEV = Thermestatic Expansion Value
Resistor = Resistor					I.E.V. = Inermostatic Expansion Valve



IDPlus 971: TERMINALS							
*	1-2: Compressor relay	TTL	TTL Input or Digital Input 2				
*	2-3-4: 12 Vac/dc or 5-6-7: 230 Vac → Defrost relay	10-9	Probe Pb1				
Supply	6-7: models 12 Vac/dc or 3-4: models 230 Vac	10-8	Probe Pb2				
Ň-L	230 Vac power supply	10-11	Digital Input 1/ Pb3 probe				





D.1.2

NO-

10-

F = Functions H = Inputs and Outputs R = Relay Output	AP1	AP2	AP3	AP4
Cold application	Х	Х	Х	Х
F - End defrost by temperature	Х	Х	Х	Х
F - HACCP		Х		
F - Alarm on Pb1	Х	Х	Х	Х
H - Pb1 present	Х	Х	Х	Х
H - Pb2 present	Х	Х	Х	Х
H - Pb3 / D.I.1 enabled		Pb3	D.I.	
H - Buzzer	Х	Х	Х	Х
R - Compressor	Х	Х	Х	Х
R - Heating elements	Х	Х		
R - Fans	Х	Х	Х	Х
R - Auxiliary			Х	
R - Reversing valve				Х

Application settings

IDPlus	974: TERMINALS	1	
X	0-2: Fans relay	10-9	probe Pb1
*	1-2: Compressor relay	10-8	probe Pb2
*	2-3-4: 12 Vac/dc or 5-6-7: 230 Vac → Defrost relay	10-11	Digital Input 1/ Pb3 probe
Supply	6-7: models 12 Vac/dc or 3-4: models 230 Vac	TTL	TTL Input or Digital Input 2
Ň-L	230Vac power supply		

(H11≠0 and H43=n)



LOADING DEFAULT APPLICATIONS

The procedure used to load one of the default applications is:

- when the instrument switches on, press and hold the set key: the label "AP1" will appear;
- scroll through the various applications (AP1-AP2-AP3-AP4) using the S and S keys;
- select the desired application using the key (AP3" in the example) or cancel the procedure by pressing the key (); alternatively wait for the timeout;
- if the operation is successful, the display will show "y", otherwise "n" will appear;
- after a few seconds the instrument will return to the main display.



LOCK SETPOINT MODIFICATION

The keypad can be locked by entering the "Basic Commands" menu using ce and pressing () and () within 2 seconds, or by programming the "LOC" parameter (see "dis" folder). If the keypad is locked, the "Basic Commands" menu can be accessed and the Setpoint displayed, but the value cannot be modified.

INSTRUMENT ON/OFF

The instrument can be switched off by pressing the key 🌑 for longer than 5 seconds. In this condition, the adjustment algorithms and defrost cycles are disabled and the text "OFF" will appear on the display.

ACCESSING AND USING THE MENUS

Resources are organised into menus. Press and release the 🚳 key to access the "Machine Status" menu. To access the "Programming" menu, press the 🚳 key for more than 5 seconds. If no keys are pressed for over 15 seconds (Timeout), or if the where the second s

MANUAL DEFROST CYCLE ACTIVATION

Hold down the 🔿 key for longer than 5 seconds. It is only activates if the temperature conditions are fulfilled. Otherwise, the display will flash three times to indicate that the operation will not be performed.

MOUNTING - DIMENSIONS

The device is designed for panel mounting. Drill a 29x71 mm hole and insert the instrument; secure it with the special brackets provided. Do not install the instrument in damp and/or dirty places; in fact, it is suitable for use in places with ordinary or normal levels of pollution. Keep the area around the instrument cooling slots adequately ventilated.



DIAGNOSTICS

Alarms are always indicated by the buzzer (if present) and the alarm icon (...)

To switch off the buzzer, press and release any key; the corresponding icon will continue to flash.

N.B.: If alarm exclusion times have been set (see "AL" folder) the alarm will not be signalled.

In the event of an alarm caused by a malfunctioning ambient probe (Pb1), the indication "E1" will appear on the display. For a malfunctioning evaporator probe (Pb2), the indication "E2" will appear (**IDPlus 971/974 only**).

Finally, for a malfunctioning Pb3 probe, the indication "E3" will appear on the display.

	ALARMS								
Label	Fault	Cause	Effects	Remedy					
E1	Cold room probe1 faulty	measured values are outside operating range Probe faulty/short-circuited/open	Display label E1 Alarm icon permanently on Disable max/min alarm controller Compressor operation based on parameters "Ont" and "OFt".	check probe type (par. H00) check probe wiring replace probe					
E2	Defrost probe2 faulty only on IDPlus 971/974	measured values are outside operating range probe faulty/short-circuited/open	Display label E2 Alarm icon permanently on The Defrost will end due to Timeout (dEt) The evaporator fans will be: on if the compressor is ON, or running in accordance with the FCO parameter if the compressor is OFF	 check probe type (par. H00) check probe wiring replace probe 					
E3	Probe3 faulty	 measured values are outside operating range probe faulty/short-circuited/open 	 Display label E3 Alarm icon permanently on 	 check probe type (par. H00) check probe wiring replace probe 					
AH1	Alarm for HIGH Pb1 temperature	value read by Pb1 > HAL after time of " tAO " (see "MAX/MIN TEMP. ALARMS)	 Recording of label AH1 in folder AL No effect on regulation 	Wait until value read by Pb1 returns below HAL					
AL1	Alarm for LOW Pb1 temperature	value read by Pb1 < LAL after time of " tAO " (see "MAX/MIN TEMP. ALARMS)	 Recording of label AL1 in folder AL No effect on regulation 	Wait until value read by Pb1 returns above LAL					
EA	External alarm	Digital input activated $(H11 = \pm 5)$	 Recording of label EA in folder AL Alarm icon permanently on Regulation locked if rLO = y 	check and remove the external cause which triggered the alarm on the D.I.					
OPd	Door open alarm	digital input activation (H11 = ± 4) (for longer than tdO)	Recording of label Opd in folder AL Alarm icon permanently on Controller locked	 close the door delay function defined by OAO 					
Ad2	Defrost due to timeout	end of defrost cycle due to timeout rather than due to defrost end temperature being recorded by Pb2	 Recording of label Ad2 in folder AL Alarm icon permanently on 	wait for the next defrost cycle for automatic return					

Label	Fault	Cause	Effects	Remedy
сон	Over Heating alarm	Pb3 value set by parameter SA3 exceeded	Recording of label COH in folder AL Alarm icon permanently on Regulation locked (Compressor)	 wait for the temperature to return to a value of SA3 (Setpoint) minus dA3 (differential)
nPA	General pressure switch alarm	Activation of pressure alarm by general pressure switch	If the number N of pressure switch activations is: N < PEn: • Recording of folder nPA in folder AL, with the number of pressure switch activations • Regulation locked (Compressor and Fans)	check and remove the cause which triggered the alarm on the D.I. (Automatic Reset)
PAL	General pressure switch alarm	Activation of pressure alarm by general pressure switch	If the number N of pressure switch activations is: N = PEn: • Display label PAL • Recording of label PA in folder AL • Alarm LED steady • Regulation locked (Compressor and Fans)	 Switch the device off and back on again Reset alarms by entering the functions folder and selecting the rAP function (Manual Reset)
HC n	Max/Min Pb3 value when out of range (SLH SHH)	Logs the Max/Min value recorded by Pb3 when it exceeds range SLHSHH. "n" represents the sequential number of times the range is exceeded.	 Recording of folder "HC n" in folder AL Alarm LED steady No effect on regulation 	NB : " n " can assume the values 1 to 8. If $\mathbf{n} > 8$, folder HC8 will flash and the system will overwrite folders where $\mathbf{n}=1$
tC n	Pb3 out-of-range dwell time (SLHSHH)	Stores the dwell time of the Pb3 value outside range SLHSHH. n " represents the sequential number of times the range is exceeded.	 Recording of folder "tC n" in folder AL Alarm LED steady No effect on regulation 	NB: "n" can assume the values 1 to 8. If n > 8, folder HC8 will flash and the system will overwrite folders where n =1
bC n	Value recorded by Pb3 on return from bOt	Logs the value recorded by Pb3 on return from a blackout. "n" represents the sequential number of blackouts that have occurred.	 Recording of folder "bC n" in folder AL No effect on regulation 	NB : " n " can assume the values 1 to 8. If $\mathbf{n} > 8$, folder bC8 will flash and the system will overwrite folders where $\mathbf{n}=1$
bt n	Pb3 out-of-range dwell time during bOt	Stores the out-of-range dwell time of the Pb3 value during a blackout. "n" represents the sequential number of blackouts that have occurred.	 Recording of folder "bt n" in folder AL. The value contained will be 0 if the value of Pb3 has remained within the range, ≠ 0 if the value has gone outside of the range No effect on regulation 	N.B.: "n" can assume the values 1 to 8. If n > 8, folder bC8 will flash and the system will overwrite folders where n=1

NOTE: to delete folders "HC n", "tC n", "bC n" and "bt n" from folder AL, start function rES in folder FnC.

PASSWORD

- Password "PA1": used to access User parameters. The password is not enabled by default (PS1=0). To enable it (PS1=0): press and hold em for longer than 5 seconds, scroll through the parameters using () and () until you see the label PS1, press () to display the value, modify it using () and (), then save it by pressing () of (). If enabled, it will be required in order to access the User parameters.
- Password "PA2": used to access Installer parameters. The password is enabled by default (PS2=15). To modify it (PS2≠15): press @ and hold for longer than 5 seconds, scroll through the parameters using @ and ♥ until you see the label PA2, press @ , set the value to "15" using @ and ♥, then confirm using @ . Scroll through the folders until you find the label difa and press @ to enter. Scroll through the parameters using @ and ♥ until you see the label PS2, press @ to display the value, modify it using @ and ♥, then save it by pressing @ or @ .

The visibility of "PA2" is as follows:

- PA1 and PA2 = 0: Press and hold co for longer than 5 seconds to display "PA1" and "PA2". It will then be possible to decide whether to access the User (PA1) or the Installer (PA2) parameters.
- 2) Otherwise: The password "PA2" is amongst the level1 parameters. If enabled, it will be required when accessing the Installer parameters; to enter it, proceed as instructed for password "PA1".

If the password entered is incorrect, the label PA1/PA2 will be displayed again and the procedure will need to be repeated.

USING THE COPY CARD

The Copy Card is connected to the serial port (TTL) and allows rapid programming of the instrument parameters. Access **Installer** parameters by entering "PA2", scroll through the folders using (a) and (b) until folder **FPr** appears. Select it using (c), scroll through the parameters using (c) and (c), then select the function using (c) (c), **UL**).

- Upload (UL): Select UL and press (2). This function uploads the programming parameters from the instrument to the card. If the procedure is a success, "y", will appear on the display, otherwise "n" will appear.
- Format (Fr): This command is used to format the copy card, (recommended when using the card for the first time). Important: the Fr parameter deletes all data present. This operation cannot be cancelled.
- Download: Connect the Copy Card when the instrument is switched off. At power-on, data is downloaded from the copy card to the instrument automatically. At the end of the lamp test, the display will show "dLy" if the operation was successful and "dLn" if not.

NOTE: After downloading, the instrument works with the settings of the new map just downloaded.

MACHINE STATUS MENU

Access the Machine Status menu by pressing <table-row> and releasing the key. If no alarms are active, the "SEt" label appears. Use the keys 🔕 and 🥯 to scroll through all the folders in the menu:



- User parameters: When accessed, the display will show the first parameter (e.g. "diF"). Press (and (to scroll through all the parameters on the current level. Select the desired parameter by pressing (to save the changes.
- Installer parameters: When accessed, the display will show the first folder (e.g. "CP"). Press (and through the folders on the current level. Select the desired folder using (a). Press (b) and (c) to scroll through the parameters in the current folder and select the parameter using (c). Press (c) and (c) to modify it and (c) to save the changes.
- NOTE: Make sure you switch the instrument off and on again each time the parameter configuration is changed, in order to prevent malfunctioning in the configuration and/or timing in progress.



LIABILITY AND RESIDUAL RISKS

ELIWELL CONTROLS SRL declines any liability for damage due to:

- installation/uses different from those specified and, in particular, not complying with the safety regulations and/or instructions given in this document;
- · use on panels that do not provide adequate protection against electric shocks, water or dust when assembled;
- use on panels allowing access to dangerous parts without the use of tools;
- · tampering with and/or modifying the product;
- installation/use on panels not complying with current standards and regulations.

DISCLAIMER

This document is the exclusive property of ELIWELL CONTROLS SRL and may not be reproduced or circulated unless expressly authorised by ELIWELL CONTROLS SRL itself.

Every care has been taken in preparing this document; nevertheless ELIWELL CONTROLS SRL cannot accept liability for any damage resulting from its use. The same applies to any person or company involved in preparing and editing this document. ELIWELL CONTROLS SRL reserves the right to make aesthetic or functional changes at any time without notice.

ELECTRICAL CONNECTIONS

Attention! Make sure the machine is switched off before working on the electrical connections.

The instrument is equipped with screw or disconnectable terminal blocks for connecting electrical cables with a max. diameter of 2.5 mm² (one wire per terminal for power connections): for the terminal ratings, see the label on the instrument.

Do not exceed the maximum permissible current; in case of higher loads, use a suitably rated contactor. Make sure the power supply voltage complies with that required by the instrument. Probes have no connection polarity and can be extended using a normal bipolar cable (note that the extension of the probes influences the electromagnetic compatibility - EMC - of the instrument: take great care with the wiring). Probe cables, power supply cables and the TTL serial cable should be routed separately from power cables.

CONDITIONS OF USE

Permitted use

For safety reasons, the instrument must be installed and used according to the instructions supplied and, in particular, parts under dangerous voltages must not be accessible in normal conditions. The device must be adequately protected from water and dust with regard to its application, and must only be accessible using tools (except for the front panel). The device is suitable for use in household refrigeration appliances and/or similar equipment and has been tested for safety aspects in accordance with the harmonised European reference standards.

Improper use

Any use other than that expressly permitted is prohibited. The relay contacts provided are of a functional type and subject to failure: any protection devices required by product standards, or suggested by common sense for obvious safety requirements, must be installed externally to the instrument.

	TECHNICAL DATA (EN 60730-2-9)
Classification:	operation (not safety) device for incorporation
Mounting:	panel mounting with 71x29 mm (+0.2/-0.1 mm) drilling template
Type of action:	1.B
Pollution class:	2
Material class:	Illa
Overvoltage category:	II
Rated impulse voltage:	2500 Vac
Temperature:	Use: -5 55 °C - Storage: -30 85 °C
Power supply:	12 Vac/dc (±10%) 50/60 Hz or 230 Vac (±10%) 50/60 Hz
Consumption:	4.5 W max
Digital outputs (relay):	refer to the label on the device
Fire resistance category:	D
Software class:	A

NOTE: check the power supply specified on the instrument label; contact our Sales Office for power supply and relay ratings.

FURTHER INFORMATION

Input Characteristics

Display range:	NTC: -50.0 110 °C; PTC: -55.0 140 °C; PT1000: -55.0 150°C (on display with 3 digits + sign)
Accuracy:	NTC, PTC, PT1000 (-55.0 70.0 °C): Better than 0.5% of full scale +1 digit
,	PT1000 (70.0 150 °C): Better than 0.6% of full scale +1 digit
Resolution:	0.1 °C
Buzzer:	YES (depending on model)
Analogue inputs:	IDPlus 902/961: 1 NTC (default)/PTC/PT1000 (parameter H00)
5 1	IDPlus 971/974: 2 NTC (default)/PTC/PT1000 (parameter H00)
Digital inputs:	IDPlus 902/961: 1 voltage free digital input;
5	IDPlus 971/974: 2 voltage free digital inputs
	N.B.: - D.I.1 can also be configured as a probe input (H11=0 and H43=y)
	- D.I.2, if activated, should be connected to terminals 1-2 of the TTL (IDPlus 971/974)

Output Characteristics

Digital outputs:

IDPlus 902:	1 OUT1 relay:	NO 8(4) A - NC 6(3) A max 250 Vac
IDPlus 961:	1 Compressor relay:	UL60730 (A) 2Hp (12FLA - 72LRA) max 240 Vac
IDPlus 971:	1 Defrost relay: 1 Compressor relay:	NO 8(4) A - NC 6(3) A max 250 Vac UL60730 (A) 2Hp (12FLA - 72LRA) max 240 Vac or
IDPlus 974:	1 Defrost relay: 1 Compressor relay: 1 Fans relay:	NO 8(4) A - NC 6(3) A max 250 Vac UL60730 (A) 2Hp (12FLA - 72LRA) max 240 Vac or 5(2) A max 250 Vac

Mechanical Characteristics

Ċ

R

recharical characteristics	
asing:	PC+ABS UL94 V-0 resin casing, polycarbonate window, thermoplastic resin keys
imensions:	front panel 78.6x37 mm, depth 59 mm (without terminals)
erminals:	screw/disconnectable terminals for cables with a diameter of 2.5 mm ²
onnectors:	TTL for connection of Copy Card + D.I.2 (IDPlus 971/974 models only)
umidity:	Use / Storage: 1090 %RH (non-condensing)
egulations	
ood Safety:	The device complies with standard EN 13485 as follows: - suitable for storage - application: air
	- climate range A
	 measurement class 1 in the range -25 15 °C (*)

(* exclusively using Eliwell probes)

NOTE: The technical specifications given in this document regarding measurement (range, accuracy, resolution, etc.) refer to the instrument and not to any accessories provided, such as the probes. This means, for example, that the error introduced by the probe must be added to the typical error of the instrument.

DESCRIPTION OF IDPlus 902/961 FAMILY

IDPlus 902/961 devices are controllers with 1 relay output, 1 temperature regulation sensor and 1 multifunctional Digital/Temperature input.

Temperature control and compressor start/stop, plus natural defrost on compressor stop. Heating function: the controller can also be used as a simple ON/OFF thermostat for heating applications.

The Digital input (D.I.) can be used for:

- Energy saving
- Defrost activation
- door switch
- Standby
- external alarm
- Deep Cooling
- pressure switch
- HACCP alarms

	TABLE OF 'USER' MENU PARAMETERS (IDPlus 902/961)									
PAR.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.			
SEt	Temperature control SEtpoint	LSE HSE	0.0	0.0	0.0	-2.0	°C/°F			
diF	Compressor relay activation differential	0.1 30.0	2.0	2.0	2.0	0.1	°C/°F			
HSE	Maximum value that can be assigned to the Setpoint	LSE 302	99.0	140	140	5.0	°C/°F			
LSE	Minimum value that can be assigned to the Setpoint	-58.0 HSE	-50.0	-55.0	-55.0	-10.0	°C/°F			
dit	Interval between the start of two consecutive defrost cycles	0 250	6			8	hours			
dEt	Defrost timeout	1 250	30			30	min			
HAL	Maximum temperature alarm	LAL 150	50.0	150	150	50.0	°C/°F			
LAL	Minimum temperature alarm	-50.0 HAL	-50.0	-50.0	-50.0	-50.0	°C/°F			
SA3	Probe 3 alarm Setpoint	-50.0 150				70.0	°C/°F			
LOC	Basic commands modification lock	n/y	n	n	n	n	flag			
PS1	PAssword 1 for access to QUICK menu parameters	0 250	0	0	0	0	num			
CA1	Calibration1. Value to be added to the value read by probe 1	-12.0 12.0	0.0	0.0	0.0	0.0	°C/°F			
CA3	Calibration3. Value to be added to the value read by probe 3	-12.0 12.0				0.0	°C/°F			
ddL	Display mode during defrost	0/1/2	0			0	num			
Ldd	Display lock disabling timeout. 0 = function disabled	0 255	30			30	min			
H43	Probe 3 present	n/y				у	flag			
rEL	firmware rELease. Reserved: read-only parameter	1	/	/	1	/	/			
tAb	tAble of parameters. Reserved: read-only parameter	/	/	1	1	/	/			

Notes: ** The USER menu parameters also include "PA2", which can be used to access the Installer menu *** For the complete list of parameters, see: APPENDIX A: Table of Installer menu parameters

	TABLE OF 'INSTALLER' MENU PARAMETERS (II	DPlus 902/9	961)				
PAR.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
SEt	Temperature control SEtpoint.	LSE HSE	0.0	0.0	0.0	-2.0	°C/°F
	COMPRESSOR ("CP" folder)						
diF	diFferential. Compressor relay activation differential.	0,130,0	2.0	2.0	2.0	0.1	°C/°F
HSE	Higher SEt. Maximum value that can be assigned to the Setpoint.	LSE302	99.0	140	140	5.0	°C/°F
LSE	Lower SEt. Minimum value that can be assigned to the Setpoint.	-58.0HSE	-50.0	-55.0	-55.0	-10.0	°C/°F
OSP	Temperature value to be added to the Setpoint if reduced set enabled (Economy function).	-30.030.0	3.0	3.0	0.0	0.0	°C/°F
Hc	Control mode. $C(0) = Cold; H(1) = Hot.$	C/H	C	C	Н	С	flag
Ont	Controller on time for faulty probe. if Ont = 1 and OFt = 0, the compressor remains on; if Ont = 1 and OFt = 0 it runs in duty cycle mode.	0 250	0	0	0	0	min
OFt	Controller off time for faulty probe. if OFt = 1 and Ont = 0, the controller remains off; if OFt = 1 and Ont > 0, it operates in duty cycle mode.	0 250	1	1	1	1	min
dOn	Compressor relay activation delay after request.	0 250	0	0	0	0	secs
dOF	Delay after switching off and subsequent activation.	0 250	0	0	0	0	min
dbi	Delay between two consecutive compressor activations.	0 250	0	0	0	0	min
0d0 (!)	Delay in activating outputs after the instrument is switched on or after a power failure. $0 = \text{not active.}$	0 250	0	0	0	0	min
dcS	Deep Cooling cycle Setpoint.	-58.0302	0.0	0.0	0.0	0.0	°C/°F
tdc	Deep Cooling cycle duration.	0 255	0	0	0	0	min
dcc	Defrost activation delay after a Deep Cooling cycle.	0 255	0	0	0	0	min
	DEFROST ("dEF" folder)						
dit	Interval between the start of two consecutive defrost cycles.	0 250	6	0	0	8	hours
dCt	Selection of count mode for the defrost interval. 0 = compressor running time; 1 = appliance running time; 2 = A defrost cycle is run at each compressor stop.	0/1/2	1	1	1	1	num

PAR.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
dOH	Delay for start of first defrost after request.	0 59	0	0	0	0	min
dEt	Defrost timeout; determines the maximum defrost duration.	1 250	30	1	1	30	min
dPO	Determines whether the instrument must enter defrost mode at start-up. $\mathbf{n}(0) = no; \mathbf{y}(1) = yes.$	n/y	n	n	n	n	flag
	ALARMS ("AL" folder)						
Att	Can be used to select absolute (Att=0) or relative (Att=1) values for HAL and LAL parameters.	0/1	0	0	0	0	num
Afd	Alarm differential.	1.0 50.0	2.0	2.0	2.0	2.0	°C/°F
HAL	Maximum temperature alarm.	LAL302	50.0	150	150	50.0	°C/°F
LAL	Minimum temperature alarm.	-58.0HAL	-50.0	-50.0	-50.0	-50.0	°C/°F
PAO	Alarm exclusion time after re-activation following a power failure.	0 10	0	0	0	0	hours
dAO	Temperature alarm exclusion time after defrost.	0 999	0	0	0	0	min
OAO	Alarm signalling delay after disabling of digital input.	0 10	0	0	0	0	hours
tdO	Delay in door open alarm activation.	0 250	0	0	0	0	min
tAO	Time delay for temperature alarm indication.	0 250	0	0	0	0	min
rLO	An external alarm locks the controllers. $\mathbf{n}(0) = \text{does not lock}; \mathbf{y}(1) = \text{locks}.$	n/y	n	n	n	n	flag
SA3	Probe 3 alarm Setpoint.	-58.0302	0.0	0.0	0.0	70.0	°C/°F
dA3	Probe 3 alarm differential.	1.0 50.0	1.0	1.0	1.0	10.0	°C/°F
	LIGHTS & DIGITAL INPUTS ("Lit" folder)						
dOd	Digital input for switching off utilities. 0 = disabled; 1 = disables fans; 2 = disables the compressor; 3 = disables fans and compressor.	0/1/2/3	0	0	0	0	num
dAd	Activation delay for digital input.	0 255	0	0	0	0	min
dCO	Compressor deactivation delay after door opened.	0 255	1	1	1	1	min
	PRESSURE SWITCH ("PrE" folder)						
Pen	Number of errors allowed per maximum/minimum pressure switch input.	0 15	0	0	0	0	num
PEI	Minimum/maximum pressure switch error count interval.	1 99	1	1	1	1	min
PEt	Delay in activating compressor after pressure switch deactivation.	0 255	0	0	0	0	min

PAR.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
	COMMUNICATION ("Add" folder)						
PtS	Communication protocol selection. $\mathbf{t}(0) = \text{Televis}; \mathbf{d}(1) = \text{Modbus}.$	t/d	t	t	t	t	flag
dEA	Index of the device inside the family (valid values from 0 to 14).	0 14	0	0	0	0	num
FAA	Device family (valid values from 0 to 14).	0 14	0	0	0	0	num
Pty	Modbus parity bit. $\mathbf{n}(0) = \text{none}; \mathbf{E}(1) = \text{even}; \mathbf{o}(2) = \text{odd}.$	n/E/o	n	n	n	n	num
StP	Modbus stop bit. 1b $(0) = 1$ bit; 2b $(1) = 2$ bit.	1b/2b	1b	1b	1b	1b	flag
	DISPLAY ('diS' folder)						
100	Basic commands modification lock. It is still possible to enter parameter	nhi	n	n	n	n	flag
LUC	programming mode and modify them. $\mathbf{n}(0) = \operatorname{no}; \mathbf{y}(1) = \operatorname{yes}.$	11/y					nay
PS1	PAssword1: if PS1≠0 is the access key to " User " parameters.	0 250	0	0	0	0	num
PS2	PAssword2: if PS2≠0 is the access key to "Installer" parameters.	0 250	15	15	15	15	num
ndt	Display with decimal point. $\mathbf{n}(0) = \operatorname{no}; \mathbf{y}(1) = \operatorname{yes}.$	n/y	у	у	у	у	flag
CA1	Calibration 1. Temperature value to be added to the Pb1 value.	-12.012.0	0.0	0.0	0.0	0.0	°C/°F
CA3	Calibration 3. Temperature value to be added to the Pb3 value.	-12.012.0	0.0	0.0	0.0	0.0	°C/°F
	Display mode during defrost. O = display temperature recorded by Pb1;						
ddL	1= lock recorded Pb1 value at the start of the defrost cycle;	0/1/2	0	0	0	0	num
	2= display the "dEF" label.						
Ldd	Timeout value for display unlock - dEF label	0 255	30	30	30	30	min
	Select the unit of measurement used when displaying the temperature recorded by						
dro	the probes. ($0 = {}^{\circ}\mathbf{C}, 1 = {}^{\circ}\mathbf{F}$).	0/1	0	0	0	0	flag
0.0	NOTE: switching between °C and °F or vice-versa DOES NOT modify the		ľ	ľ			nug
	SEt, dif values, etc. (e.g. Setpoint=10°C becomes 10°F)						
ddd	Selects type of value to display. $\mathbf{O} = \text{Setempts} 1 = \text{probe } \text{Ph}^2 2 = \text{probe } \text{Ph}^2 2 = \text{probe } \text{Ph}^2$	0/1/2/3	1	1	1	1	num
	$\mathbf{U} = \text{Selpoint}, \mathbf{I} = \text{probe PDT}, \mathbf{Z} = \text{probe PDZ}, \mathbf{S} = \text{probe PDS}$						
сцц	HACCE (HCF Toldel)	EE 0 1E0	0.0	0.0	0.0	0.0	0C/0E
	Minimum HACCP alarm signals threshold	-55.0150	0.0	0.0	0.0	0.0	0C/0E
SLFI	Minimum fine const in without sures for the substate be seconded. After this s	-33.0130	0.0	0.0	0.0	0.0	U'F
drA	White the spent in crucal range for the event to be recorded. After this a	0 99	0	0	0	0	min
dr	HACCE alarm resolt time after lact resolt	0 250	0	0	0	0	hours
UΠ		0230		I U		U	nouls

PAR.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
H50	Enable HACCP and alarm relay functions. 0 = HACCP alarms NOT enabled; 1 = HACCP alarms enabled and alarm relay NOT enabled; 2 = HACCP alarms enabled and alarm relay enabled.	0/1/2	0	0	0	0	num
H51	HACCP alarm exclusion time.	0 250	0	0	0	0	min
	CONFIGURATION ("CnF" folder) >>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>	ler are changed	, the co	ntrolle	r MUST	be pov	vered-off
H00(!)	Probe type selection. $0 = PTC$; $1 = NTC$; $2 = PT1000$.	0/1/2	1	1	1	1	num
H11	Configuration of digital input 1/polarity. 0 = disabled; ±1 = defrost; ±2 = economy Setpoint; ±3 = AUX; ±4 = door switch; ±5 = external alarm; ±6 = Standby; ±7 = pressure switch; ±8 = Deep Cooling; ±9 = disable HACCP alarm logging. NOTE: • the "+" sign indicates that the input is active if the contact is closed. • the e"- sign indicates that the input is active if the contact is closen.	-9 +9	0	0	0	0	num
H21	(IDPlus 961 only). Configurability of digital output 1 (ﷺ). 0= disabled; 1= compressor; 2= defrost; 3= fans; 4= alarm; 5= AUX; 6= Standby.	0 6	1	1	1	1	num
H22	(IDPlus 902 only). Configurability of digital output 1 (🕸). Same as H21.	0 6	1	1	1	1	num
H31	Configurability of UP key. 0 =disabled; 1 =defrost; 2 =not used; 3 =economy Setpoint; 4 =Standby; 5 =reset HACCP alarms; 6 =disable HACCP alarms; 7 =Deep Cooling.	0 7	1	0	0	1	num
H32	Configurability of DOWN key. Same as H31.	0 7	0	0	0	0	num
H43	Probe Pb3 present. $\mathbf{n}(0) = \text{not present}; \mathbf{y}(1) = \text{present}.$	n/y	n	n	n	у	flag
reL	Device version. Read-only parameter.	l í	/	/	/	1	/
tAb	tAble of parameters. Reserved: read-only parameter.	/	/	1	1	/	/
	COPY CARD ("FPr" folder)						
UL	Programming parameter transfer from instrument to Copy Card.	/	/	/	/	/	/
Fr	Format Copy Card. Erase all data contained in the Copy Card. NOTE: if parameter "Fr" is used, the data entered will be permanently lost. This operation cannot be cancelled.	/	/	/	/	/	/
	FUNCTIONS ("FnC" folder)						
rAP	Reset pressure switch alarms	/	/	/	/	/	/
rES	Reset HACCP alarms	/	/	/	/	/	/
NOTE:	If one or more parameters marked with (!) are modified, the controller MUST be switched of	f and then switch	ned on a	igain to	ensure	correct	operation.

DESCRIPTION OF IDPLUS 971 FAMILY

IDPlus 971 devices are controllers with 2 relay outputs, 2 temperature sensors (regulation and evaporator), a multifunctional Digital/Temperature input and a digital input.

The relay output can be used to control:

- compressor
- defrost heating elements
- evaporator fans
- AUX output
- temperature alarm
- Standby

The second probe can be used to control the defrost cycle and the evaporator fans.

The Digital inputs (D.I.1 and D.I.2) can be used for:

- Energy saving
- Defrost activation
- AUX management
- door switch
- Standby
- external alarm
- Deep Cooling
- pressure switch
- HACCP alarms

TABLE OF 'USER' MENU PARAMETERS (IDPlus 971)

PAR.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
SEt	Temperature control SEtpoint	LSE HSE	0,0	0,0	0,0	0,0	°C/°F
diF	Compressor relay activation differential	0,130,0	2,0	2,0	2,0	2,0	°C/°F
HSE	Maximum value that can be assigned to the Setpoint	LSE 302	99,0	99,0	99,0	99,0	°C/°F
LSE	Minimum value that can be assigned to the Setpoint	-58.0 HSE	-50,0	-50,0	-50,0	-50,0	°C/°F
dty	Type of defrost	0/1/2	0	0			num
dit	Interval between the start of two consecutive defrost cycles	0 250	6	6	6	6	hours
dEt	Defrost timeout	1 250	30	30	30	30	min
dSt	End defrost temperature	-50,0 150	8,0		8,0		°C/°F
FSt	Fans stop temperature	-50,0 150			50,0		°C/°F
Fdt	Fan activation delay after a defrost cycle	0 250			0		min
dt	Coil drainage time	0 250			0		min
dFd	To select or exclude the fans (it depends on FCO parameter)	n/y			У		flag
HAL	Maximum temperature alarm	LAL 150	50,0	50,0	50,0	50,0	°C/°F
LAL	Minimum temperature alarm	-50.0 HAL	-50,0	-50,0	-50,0	-50,0	°C/°F
dOd	Enable utility switch-off on activation of door switch	0/1/2/3			0		num
dCO	Compressor deactivation delay after door opened	0 255			1		min
LOC	Basic commands modification lock	n/y	n	n	n	n	flag
PS1	PAssword 1 for access to QUICK menu parameters	0 250	0	0	0	0	num
CA1	Calibration1. Value to be added to the value read by probe 1	-12,0 12,0	0,0	0,0	0,0	0,0	°C/°F
CA2	Calibration2. Value to be added to the value read by probe 2	-12,0 12,0	0,0		0,0		°C/°F
ddL	Display mode during defrost	0/1/2	0	0	0	0	num
Ldd	Display lock disabling timeout. 0 = function disabled	0 255	30	30	30	30	min
H42	Evaporator probe present	n/y	У		y		flag
rEL	firmware rELease. Reserved: read-only parameter	ľ	1	1	Ĩ	/	1
tAb	tAble of parameters. Reserved: read-only parameter	/	/	/	1	/	/

Notes: ** The USER menu parameters also include "PA2", which can be used to access the Installer menu. *** For the complete list of parameters, see: APPENDIX A: Table of Installer menu parameters.

	TABLE OF 'INSTALLER' MENU PARAMETERS	(IDPlus 971	1)				
PAR.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
SEt	Temperature control SEtpoint.	LSE HSE	0,0	0,0	0,0	0,0	°C/°F
	COMPRESSOR ("CP" folder)						
diF	diFferential. Compressor relay activation differential.	0,130,0	2,0	2,0	2,0	2,0	°C/°F
HSE	Higher SEt. Maximum value that can be assigned to the Setpoint.	LSE302	99,0	99,0	99,0	99,0	°C/°F
LSE	Lower SEt. Minimum value that can be assigned to the Setpoint.	-58.0HSE	-50,0	-50,0	-50,0	-50,0	°C/°F
OSP	Temperature value to be added to the Setpoint if reduced set enabled (Economy function).	-30,030,0	3,0	3,0	0,0	3,0	°C/°F
Hc	Control mode. $C(0) = Cold; H(1) = Hot.$	C/H	С	С	С	С	flag
Ont	Controller on time for faulty probe. If Ont = 1 and OFt = 0 , the compressor remains on; if Ont = 1 and OFt > 0 it runs in duty cycle mode.	0 250	0	0	0	0	min
OFt	Controller off time for faulty probe. If OFt = 1 and Ont = 0 , the controller remains off; if OFt = 1 and Ont >0 , it operates in duty cycle mode.	0 250	1	1	1	1	min
dOn	Compressor relay activation delay after request	0 250	0	0	0	0	secs
dOF	Delay after switching off and subsequent activation	0 250	0	0	0	0	min
dbi	Delay between two consecutive compressor activations	0 250	0	0	0	0	min
0d0 (!)	Delay in activating outputs after the instrument is switched on or after a power failure. $0 = \text{not}$ active.	0 250	0	0	0	0	min
dcS	Deep Cooling cycle Setpoint.	-58,0302	0,0	0,0	0,0	0,0	°C/°F
tdc	Deep Cooling cycle duration.	0 255	0	0	0	0	min
dcc	Defrost activation delay after a Deep Cooling cycle.	0 255	0	0	0	0	min
	DEFROST ("dEF" folder)						
dtY	Type of defrost. 0 = electrical defrost; 1 = reverse cycle defrost; 2 = defrost independent of compressor.	0/1/2	0	0	0	0	num
dit	Interval between the start of two consecutive defrost cycles.	0 250	6	6	6	6	hours

PAR.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
10	Selection of count mode for the defrost interval.	0/1/0	1	1	1	1	
act	$\mathbf{U} = \text{compressor running time; } 1 = \text{appliance running time;}$	0/1/2	1	1			num
401	Z = A denost cycle is full at each complessor stop.	0 50	0	0	0	0	min
dEt	Defay for start of first defaust after request.	1 250	30	30	30	30	min
dSt	Defrost and temperature - determined by the evaporator probe	-50.0 150	80	50.0	8.0	50.0	°C/°E
ust	Determines whether the instrument must enter defrost mode at start-up	-30,0130	0,0	30,0	0,0	30,0	0/1
dPO	$\mathbf{n}(0) = \mathbf{n}_0 \cdot \mathbf{v}(1) = \mathbf{v}_0$	n/y	n	n	n	n	flag
	FANS ("FAn" folder)						
FSt	Eans stop temperature	-58.0 302	50.0	50.0	50.0	50.0	°C/°E
FAd	Fan activation differential	1.0 50.0	2.0	2.0	2.0	2.0	°C/°F
Fdt	Fan activation delay after a defrost cycle.	0250	0	0	0	0	min
dt	Coil drainage time.	0250	0	0	0	0	min
dEd	Allows evaporator fan exclusion to be selected or not selected during defrosting.	nlu					flag
uru	$\mathbf{y}(0) = \text{yes}(\text{fans excluded}); \mathbf{n}(1) = \text{no}(\text{it depends on FCO parameter}).$	п/у	У	У	у	у	nay
FCO	Selects or deselects fan deactivation at compressor OFF.	0/1/2	0	0	0	0	num
100	0 = fans off; 1 = fans active; 2 = duty cycle.	0/1/2	- U		0	0	num
FOn	Fans ON time in day duty cycle.	0 99	0	0	0	0	min
FOF	Fans OFF time in day duty cycle.	0 99	0	0	0	0	min
Fnn	Fans ON time in night duty cycle.	099	0	0	0	0	min
FnF	Fans OFF time in night duty cycle.	099	0	0	0	0	min
ESF	Night mode activation. $\mathbf{n}(0) = no; \mathbf{y}(1) = yes.$	n/y	n	n	n	n	flag
	ALARMS ("AL" folder)						
Δ++	Can be used to select absolute (Att=0) or relative (Att=1) values for HAL and LAL	0/1	0	0	0	0	num
	parameters.	0/1					
Afd	Alarm differential.	1,0 50,0	2,0	2,0	2,0	2,0	°C/°F
HAL	Maximum temperature alarm.	LAL302	50,0	50,0	50,0	50,0	°C/°F
LAL	Minimum temperature alarm.	-58.0HAL	-50,0	-50,0	-50,0	-50,0	°C/°F
PAO	Alarm exclusion time after re-activation following a power failure.	010	0	0	0	0	hours
dAO	Temperature alarm exclusion time after defrost.	0999	0	0	0	0	min

PAR.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
0A0	Alarm signalling delay after disabling of digital input.	0 10	0	0	0	0	hours
td0	Delay in door open alarm activation.	0 250	0	0	0	0	min
tAO	Time delay for temperature alarm indication.	0 250	0	0	0	0	min
dAt	Alarm signalling end of defrost due to timeout. $\mathbf{n}(0) = \operatorname{no}; \mathbf{y}(1) = \operatorname{yes}.$	n/y	n	n	n	n	flag
rLO	External alarm locks controllers. $\mathbf{n}(0) = \text{does not lock}; \mathbf{y}(1) = \text{locks}.$	n/y	n	n	n	n	flag
SA3	Probe 3 alarm Setpoint.	-58,0+302	0,0	0,0	0,0	0,0	°C/°F
dA3	Probe 3 alarm differential.	1,0 50,0	1,0	1,0	1,0	1,0	°C/°F
	LIGHTS & DIGITAL INPUTS ("Lit" folder)						
404	Digital input for switching off utilities. 0 =disabled;	0/1/2/2	0	0	2	0	
dua	1=disables fans; 2=disables the compressor; 3=disables fans and compressor.	0/1/2/3	0	0	2	0	num
dAd	Activation delay for digital input.	0 255	0	0	0	0	min
dCO	Compressor deactivation delay after door opened.	0 255	1	1	1	1	min
	PRESSURE SWITCH ("PrE" folder)						
Pen	Number of errors allowed per maximum/minimum pressure switch input.	0 15	0	0	0	0	num
PEI	Minimum/maximum pressure switch error count interval.	1 99	1	1	1	1	min
PEt	Delay in activating compressor after pressure switch deactivation.	0 255	0	0	0	0	min
	COMMUNICATION ("Add" folder)						
PtS	Communication protocol selection. $\mathbf{t}(0) = \text{Televis}; \mathbf{d}(1) = \text{Modbus}.$	t/d	t	t	t	t	flag
dEA	Index of the device inside the family (valid values from 0 to 14).	0 14	0	0	0	0	num
FAA	Device family (valid values from 0 to 14).	0 14	0	0	0	0	num
Pty	Modbus parity bit. $\mathbf{n}(0) = \text{none}; \mathbf{E}(1) = \text{even}; \mathbf{o}(2) = \text{odd}.$	n/E/o	n	n	n	n	num
StP	Modbus stop bit. 1b $(0) = 1$ bit; 2b $(1) = 2$ bit.	1b/2b	1b	1b	1b	1b	flag
	DISPLAY ("diS" folder)						
100	Basic commands modification lock. It is still possible to enter parameter	nhu					flag
LUC	programming mode and modify them. $\mathbf{n}(0) = \operatorname{no}; \mathbf{y}(1) = \operatorname{yes}.$	п/у					llay
PS1	PAssword1: if PS1≠0 is the access key to User parameters.	0 250	0	0	0	0	num
PS2	PAssword2: if PS2≠0 is the access key to Installer parameters.	0 250	15	15	15	15	num
ndt	Display with decimal point. $\mathbf{n}(0) = \operatorname{no}; \mathbf{y}(1) = \operatorname{yes}.$	n/y	у	у	у	у	flag
CA1	Calibration 1. Temperature value to be added to the Pb1 value.	-12,0+12,0	0,0	0,0	0,0	0,0	°C/°F

PAR.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
CA2	Calibration 2. Temperature value to be added to the Pb2 value.	-12,0+12,0	0,0	0,0	0,0	0,0	°C/°F
CA3	Calibration 3. Temperature value to be added to the Pb3 value.	-12,0+12,0	0,0	0,0	0,0	0,0	°C/°F
	Display mode during defrost.						
ddL	0= display the temperature recorded by Pb1;	0/1/2	0	0	0	0	num
	1 = lock recorded value of Pb1 at defrost start; 2 = display the "dEF" label.						
Ldd	Timeout value for display unlock - dEF label.	0 255	30	30	30	30	min
	Select the unit of measurement used when displaying the temperature recorded by						
dro	the probes. ($0 = {}^{\circ}C, 1 = {}^{\circ}F$).	0/1	0	0	0	0	flag
0.0	NOTE: switching between °C and °F or vice-versa DOES NOT modify the SEt, diF		Ū	Ū	Ů	ľ	neg
	values, etc. (e.g. Setpoint=10°C becomes 10°F).						
ddd	Selects the type of value to display.	0/1/2/3	1	1	1	1	num
	$ \mathbf{U} - \text{Setpoint}, \mathbf{I} - \text{probe PDT}, \mathbf{Z} - \text{probe PDZ}, \mathbf{S} - \text{probe PDS}.$						
СПП	HACCE (HCF 1010er)	EE 0 1E0	0	0	0	0	0 <i>C /</i> 0E
200	Minimum HACCP alarm signals threshold	-55,0150	0	0	0	0	0C/0E
SLH	Minimum HACCP diarm signals uneshold.	-55,0150	0	0	0	0	·U/F
drA	Minimum time spent in critical range for the event to be recorded. After this a	0 99	0	0	0	0	min
dell	HACCP alarm will be inggered and logged.	0 250	0	0	0	0	houre
arn	FACCP diditil reset time diter last reset.	0230	0	0	0	0	nours
450	I = HACCP alarms enabled and alarm relay NOT enabled:	0/1/2	0	0	0	0	num
1150	2 = HACCP alarms enabled and alarm relay not enabled	0/1/2					num
H51	HACCP alarm exclusion time	0 250	0	0	0	0	min
1101	CONFIGURATION ("CDE" folder) If one or more parameters present in this ford	ar are changed	the cou	atrollar	MUCT	ha nau	arad off
	and than powered-on.	er ale changeu,	the col	uoner	WUSI	ne how	erea-on
H00 (!)	Probe type selection. $0 = PTC$; $1 = NTC$; $2 = PT1000$.	0/1/2	1	1	1	1	num
	Configuration of digital input 1/polarity. $0 = \text{disabled}; \pm 1 = \text{defrost}; \pm 2 = \text{economy}$						
	Setpoint; ±3= AUX; ±4= door switch; ±5 = external alarm; ±6= Standby;						
H11	±7= pressure switch; ±8= Deep Cooling; ±9= disable HACCP alarm logging.	-9 +9	0	0	4	0	num
	NOTE: • the "+" sign indicates that the input is active if the contact is closed.						
	 the "-" sign indicates that the input is active if the contact is open. 						

PAR.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
H12	Configuration of digital input 2/polarity. Same as H11.	-9 +9	0	0	0	0	num
H21	Configurability of digital output 1 (\$\$). 0 = disabled; 1 = compressor; 2 = defrost; 3 = fans; 4 = alarn; 5 = AUX; 6 = Standby.	0 6	1	1	1	1	num
H22	Configurability of digital output 2 (🚓). Same as H21.	0 6	2	2	3	4	num
H25	Enable/Disable buzzer. 0= Disabled; 4= Enabled; 1-2-3-5-6-7-8 =not used.	0 8	0	0	0	4	num
H31	Configurability of UP key. 0 = disabled; 1 = defrost; 2 = AUX; 3 = economy Setpoint; 4 = Standby; 5 = reset HACCP alarms; 6 = disable HACCP alarms; 7 = Deep Cooling.	0 7	1	1	1	1	num
H32	Configurability of DOWN key. Same as H31.	0 7	0	0	0	0	num
H42	Evaporator probe present. $\mathbf{n}(0) = \text{not present}; \mathbf{y}(1) = \text{present}.$	n/y	у	n	у	n	flag
H43	Probe 3 present. $\mathbf{n}(0) = \text{not present}; \mathbf{y}(1) = \text{present}.$	n/y	n	n	n	n	flag
reL	Device version. Read-only parameter.	/	/	1	/	/	1
tAb	tAble of parameters. Reserved: read-only parameter.	/	/	/	/	/	/
	COPY CARD ("FPr" folder)						
UL	Programming parameter transfer from instrument to Copy Card.	/	/	/	/	/	1
Er	Format Copy Card. Erase all data contained in the Copy Card.	,	,	,	,	,	,
1	NOTE: If parameter is used, the data entered will be permanently	/	'	· /	'	'	'
	ELINCTIONS ("EnC" folder)						
rΔP	Reset pressure switch alarms	/	1	1	1	1	/
rES	Reset HACCP alarms.	1	1	1	1	Γ́Γ	,

NOTE: If one or more parameters marked with (!) are modified, the controller MUST be switched off and then switched on again to ensure correct operation.

DESCRIPTION OF IDPlus 974 FAMILY

IDPlus 974 devices are controllers with 3 relay outputs, 2 temperature sensors (regulation and evaporator), a multifunctional Digital/Temperature input and a digital input.

Relay outputs 2 and 3 can be used to control:

- compressor
- defrost heating elements
- evaporator fans
- AUX output
- alarm
- Standby

The second probe can be used to control the defrost cycle and the evaporator fans.

The Digital inputs (D.I.1 and D.I.2) can be used for:

- Energy Saving
- Defrost activation
- AUX management
- door switch
- Standby
- external alarm
- Deep Cooling
- pressure switch
- HACCP alarms

	TABLE OF USER MENU PARAMETERS (IDPlus 974)											
PAR.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.					
SEt	Temperature control SEtpoint	LSE HSE	0,0	0,0	0,0	0,0	°C/°F					
diF	Compressor relay activation differential	0,130,0	2,0	2,0	2,0	2,0	°C/°F					
HSE	Maximum value that can be assigned to the Setpoint	LSE 302	99.0	99.0	99.0	99.0	°C/°F					
LSE	Minimum value that can be assigned to the Setpoint	-58.0 HSE	-50,0	-50,0	-50,0	-50,0	°C/°F					
dty	Type of defrost	0/1/2	0	0		1	num					
dit	Interval between the start of two consecutive defrost cycles	0 250	6	6	6	6	hours					
dEt	Defrost timeout	1 250	30	30	30	30	min					
dSt	End defrost temperature	-50,0 150	8,0	8,0	8,0	8,0	°C/°F					
FSt	Fans stop temperature	-58,0 302	50,0	50,0	50,0	50,0	°C/°F					
Fdt	Fan activation delay after a defrost cycle	0 250	0	0	0	0	min					
dt	Coil drainage time	0 250	0	0	0	0	min					
dFd	To select or exclude the fans (it depends on FCO parameter)	n/y	V	y	y	V V	min					
HAL	Maximum temperature alarm	LAL 150	50,0	50,0	50,0	50,0	°C/°F					
LAL	Minimum temperature alarm	-50.0 HAL	-50,0	-50,0	-50,0	-50,0	°C/°F					
LOC	Basic commands modification lock	n/y	n	n	n	n	flag					
PS1	PAssword 1 for access to QUICK menu parameters	0 250	0	0	0	0	num					
CA1	Calibration1. Value to be added to the value read by probe 1	-12,0 12,0	0,0	0,0	0,0	0,0	°C/°F					
CA2	Calibration2. Value to be added to the value read by probe 2	-12,0 12,0	0,0	0,0	0,0	0,0	°C/°F					
CA3	Calibration 3. Value to be added to the value read by probe 3	-12,0 12,0	0,0	0,0		0,0	°C/°F					
ddL	Display mode during defrost	0/1/2	0	0	0	0	num					
Ldd	Display lock disabling timeout. 0 = function disabled	0 255	30	30	30	30	min					
SHH	Maximum HACCP alarm signals threshold	-55,0 150		10,0			°C/°F					
SLH	Minimum HACCP alarm signals threshold	-55,0 <u>1</u> 50		-10,0			°C/°F					
drA	Minimum time spent in critical range before alarm occurs	0 99		10			min					
drH	HACCP alarm reset time after last reset	0 250		24			hours					
H50	enable HACCP and alarm relay functions	0/1/2		1			num					
H51	HACCP alarm exclusion time	0 250		0			min					
H42	Evaporator probe present. n = not present; y = present	n/y	У	у	у	y y	flag					
H43	Probe 3 present	n/ý	ń	ý	ń	ń	flag					
rEL	firmware rELease. Reserved: read-only parameter	1	/	1		/						
tAb	ItAble of parameters. Reserved: read-only parameter	/										
Notes:	* The USER menu parameters also include: PA2, which can be used t	o access the Instal	ler meni	1								

* The USER menu parameters also include: **PA2**, which can be used to access the Installer menu ** To reset the HACCP alarms, use the rES function in the FnC folder for Installer parameters *** For the complete list of parameters, see: APPENDIX A: **Table of** Installer menu parameters

	TABLE OF INSTALLER MENU PARAMETERS	IDPlus 974)				
PAR.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
SEt	Temperature control SEtpoint.	LSE HSE	0.0	0.0	0.0	0.0	°C/°F
	COMPRESSOR ("CP" folder)						
diF	diFferential. Compressor relay activation differential.	0,130,0	2,0	2,0	2,0	2,0	°C/°F
HSE	Higher SEt. Maximum value that can be assigned to the Setpoint.	LSE302	99,0	99,0	99,0	99,0	°C/°F
LSE	Lower SEt. Minimum value that can be assigned to the Setpoint.	-58,0HSE	-50,0	-50,0	-50,0	-50,0	°C/°F
OSP	Temperature value to be added to the Setpoint if reduced set enabled (Economy function).	-30,030,0	3,0	0,0	0,0	3,0	°C/°F
Hc	Control mode. $C(0) = Cold; H(1) = Hot.$	C/H	С	С	C	С	flag
Ont	Controller on time for faulty probe. If Ont = 1 and OFt = 0 , the compressor remains on; if Ont = 1 and OFt>0 it runs in duty cycle mode.	0 250	0	0	0	0	min
OFt	Controller off time for faulty probe. If OFt = 1 and Ont = 0 , the controller remains off; if OFt = 1 and Ont>0 , it operates in duty cycle mode.	0 250	1	1	1	1	min
dOn	Compressor relay activation delay after request.	0 250	0	0	0	0	secs
dOF	Delay after switching off and subsequent activation.	0 250	0	0	0	0	min
dbi	Delay between two consecutive compressor activations.	0 250	0	0	0	0	min
0d0 (!)	Delay in activating outputs after the instrument is switched on or after a power failure. $0 = \text{not active}$.	0 250	0	0	0	0	min
dcS	Deep Cooling cycle Setpoint.	-58,0302	0,0	0,0	0,0	0,0	°C/°F
tdc	Deep Cooling cycle duration.	0 255	0	0	0	0	min
dcc	Defrost activation delay after a Deep Cooling cycle.	0 255	0	0	0	0	min
	DEFROST ("dEF" folder)						
dtY	Type of defrost. 0 = electrical defrost; 1 = reverse cycle defrost; 2 = defrost independent of compressor.	0/1/2	0	0	0	1	num
dit	Interval between the start of two consecutive defrost cycles.	0 250	6	6	6	6	hours
dCt	Selection of count mode for the defrost interval. 0 = compressor running time; 1 = appliance running time; 2 = A defrost cycle is run at each compressor stop.	0/1/2	1	1	1	1	num

PAR.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
dOH	Delay for start of first defrost after request.	0 59	0	0	0	0	min
dEt	Defrost timeout; determines the maximum defrost duration.	1 250	30	30	30	30	min
dSt	Defrost end temperature - determined by probe Pb2.	-50,0150	8,0	8,0	8,0	50,0	°C/°F
dDO	Determines whether the instrument must enter defrost mode at start-up.	nhi					flag
uru	n(0) = no; y(1) = yes.	n/y	п	п	п	п	nag
	FANS ("FAn" folder)						
FSt	Fans stop temperature.	-58,0302	50,0	50,0	50,0	50,0	°C/°F
FAd	Fan activation differential.	1,0 50,0	2,0	2,0	2,0	2,0	°C/°F
Fdt	Fan activation delay after a defrost cycle.	0 250	0	0	0	0	min
dt	Coil drainage time.	0 250	0	0	0	0	min
dEd	Allows evaporator fan exclusion to be selected or not selected during defrosting.	nhi					flag
uru	n (0) = no (it depends on FCO parameter); y (1) = yes (fans excluded).	11/y	у	у	у	у	nay
FCO	Selects or deselects fan deactivation at compressor OFF.	0/1/2	0	0	0	0	num
100	0 = fans off; 1 = fans active; 2 = duty cycle	0/1/2	0	0	0	0	num
FOn	Fans ON time in day duty cycle.	0 99	0	0	0	0	min
FOF	Fans OFF time in day duty cycle.	0 99	0	0	0	0	min
Fnn	Fans ON time in night duty cycle.	0 99	0	0	0	0	min
FnF	Fans OFF time in night duty cycle.	0 99	0	0	0	0	min
ESF	Night mode activation. $\mathbf{n}(0) = \operatorname{no}; \mathbf{y}(1) = \operatorname{yes}.$	n/y	n	n	n	n	flag
	ALARMS ("AL" folder)						
Δ++	Can be used to select absolute (Att=0) or relative (Att=1) values for HAL and LAL	0/1	0	0	0	0	0.000
All	parameters.	0/1	0	0	0	0	num
Afd	Alarm differential.	1,0 50,0	2,0	2,0	2,0	2,0	°C/°F
HAL	Maximum temperature alarm.	LAL302	50,0	50,0	50,0	50,0	°C/°F
LAL	Minimum temperature alarm.	-58,0HAL	-50,0	-50,0	-50,0	-50,0	°C/°F
PAO	Alarm exclusion time after re-activation following a power failure.	0 10	0	0	0	0	hours
dAO	Temperature alarm exclusion time after defrost.	0 999	0	0	0	0	min
OAO	Alarm signalling delay after disabling of digital input.	0 10	0	0	0	0	hours
tdO	Delay in door open alarm activation.	0 250	0	0	0	0	min
tAO	Time delay for temperature alarm indication.	0 250	0	0	0	0	min

PAR.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
dAt	Alarm signalling end of defrost due to timeout. $\mathbf{n}(0) = \operatorname{no}; \mathbf{y}(1) = \operatorname{yes}.$	n/y	n	n	n	n	flag
rLO	External alarm locks controllers. $\mathbf{n}(0) = \text{does not lock}; \mathbf{y}(1) = \text{locks}.$	n/y	n	n	n	n	flag
SA3	Probe 3 alarm Setpoint.	-58,0302	0,0	0,0	0,0	0,0	°C/°F
dA3	Probe 3 alarm differential.	1,0 50,0	1,0	1,0	1,0	1,0	°C/°F
	LIGHTS & DIGITAL INPUTS ("Lit" folder)						
dOd	Digital input for switching off utilities. 0 =disabled; 1 =disables fans; 2 =disables the compressor; 3 =disables fans and compressor.	0/1/2/3	0	0	0	0	num
dAd	Activation delay for digital input.	0 255	0	0	0	0	min
dCO	Compressor deactivation delay after door opened.	0 255	1	1	1	1	min
AuP	Aux output activation when door opened. $\mathbf{n}(0) = \text{not linked}; \mathbf{y}(1) = \text{linked}.$	n/y	n	n	у	n	flag
	PRESSURE SWITCH ("PrE" folder)						
Pen	Number of errors allowed per maximum/minimum pressure switch input.	0 15	0	0	0	0	num
PEI	Minimum/maximum pressure switch error count interval.	1 99	1	1	1	1	min
PEt	Delay in activating compressor after pressure switch deactivation.	0 255	0	0	0	0	min
	COMMUNICATION ("Add" folder)			_			
PtS	Communication protocol selection. $\mathbf{t}(0) = \text{Televis}; \mathbf{d}(1) = \text{Modbus}.$	t/d	t	t	t	t	flag
dEA	Index of the device inside the family (valid values from 0 to 14).	0 14	0	0	0	0	num
FAA	Device family (valid values from 0 to 14).	0 14	0	0	0	0	num
Pty	Modbus parity bit. $\mathbf{n}(0) = \text{none}$; $\mathbf{E}(1) = \text{even}$; $\mathbf{o}(2) = \text{odd}$.	n/E/o	n	n	n	n	num
StP	Modbus stop bit. 1b $(0) = 1$ bit; 2b $(1) = 2$ bit.	1b/2b	1b	1b	1b	1b	flag
	DISPLAY ("diS" folder)						
100	Basic commands modification lock. It is still possible to enter parameter	n/v	n	n	n	n	flag
200	programming mode and modify them. $\mathbf{n}(0) = no; \mathbf{y}(1) = yes.$		-				nug
PS1	PAssword1: if PS1≠0 is the access key to User parameters.	0250	0	0	0	0	num
PS2	PAssword2: if PS2≠0 is the access key to Installer parameters.	0250	15	15	15	15	num
ndt	Display with decimal point. $\mathbf{n}(0) = \text{no; } \mathbf{y}(1) = \text{yes.}$	n/y	у	у	у	у	flag
CA1	Calibration 1. Iemperature value to be added to the Pb1 value.	-12,0+12,0	0,0	0,0	0,0	0,0	°C/°F
CA2	Calibration 2. Iemperature value to be added to the Pb2 value.	-12,0+12,0	0,0	0,0	0,0	0,0	°C/°F
CA3	Calibration 3. Temperature value to be added to the Pb3 value.	-12,0+12,0	0,0	0,0	0,0	0,0	°C/°F

PAR.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
ddL	Display mode during defrost. 0 = display the temperature recorded by Pb1; 1 = lock recorded value of Pb1 at defrost start; 2 = display the "dEF" label.	0/1/2	0	0	0	0	num
Ldd	Timeout value for display unlock - dEF label.	0 255	30	30	30	30	min
dro	Select the unit of measurement used when displaying the temperature recorded by the probes. ($0 = {}^\circ \mathbf{C}, 1 = {}^\circ \mathbf{P}$). NOTE: switching between °C and °F or viceversa DOES NOT modify the SEt, diF values, etc. (e.g. Setpoint=10°C becomes 10°F).	0/1	0	0	0	0	flag
ddd	Selects the type of value to display. 0 = Setpoint; 1 = probe Pb1; 2 = probe Pb2; 3 = probe Pb3.	0/1/2/3	1	1	1	1	num
	HACCP ("HCP" folder)						
SHH	Maximum HACCP alarm signals threshold.	-55,0150	0	10	0	0	°C/°F
SLH	Minimum HACCP alarm signals threshold.	-55,0150	0	-10	0	0	°C/°F
drA	Minimum time spent in critical range for the event to be recorded. After this a HACCP alarm will be triggered and logged.	0 99	0	10	0	0	min
drH	HACCP alarm reset time after last reset.	0 250	0	24	0	0	hours
H50	Enable HACCP and alarm relay functions. 0 = HACCP alarms NOT enabled; 1 = HACCP alarms enabled and alarm relay NOT enabled; 2 = HACCP alarms enabled and alarm relay enabled.	0/1/2	0	1	0	0	num
H51	HACCP alarm exclusion time.	0 250	0	0	0	0	min
	CONFIGURATION ("CnF" folder) >>>> If one or more parameters present in this forder and than powered-on.	er are changed,	the co	ntroller	MUST	be pow	rered-off
H00(!)	Probe type selection. $0 = PTC$; $1 = NTC$; $2 = PT1000$.	0/1/2	1	1	1	1	num
H11	Configuration of digital input 1/polarity. 0 = disabled; ±1 = defrost; ±2 = economy Setpoint; ±3= AUX; ±4= door switch; ±5 = external alarm; ±6= Standby; ±7= pressure switch; ±8= Deep Cooling; ±9= disable HACCP alarm logging.	-9 +9	0	0	4	0	num
	• the "-" sign indicates that the input is active if the contact is closed.						
H12	Configuration of digital input 2/polarity. Same as H11.	-9 +9	0	0	0	0	num

PAR.	DESCRIPTION	RANGE	AP1	AP2	AP3	AP4	M.U.
	Configurability of digital output 1 (ﷺ).						
H21	0 = disabled; 1 = compressor; 2 = defrost; 3 = fans;	06	1	1	1	1	num
	4 = alarm; 5 = AUX; 6 = Standby.						
H22	Configurability of digital output 2 (🗱). Same as H21.	06	2	2	5	2	num
H23	Configurability of digital output 3 (💸). Same as H21.	06	3	3	3	3	num
H25	Enable/Disable buzzer. 0 = Disabled; 4 =Enabled; 1-2-3-5-6-7-8 = not used.	08	0	0	0	0	num
H31	Configurability of UP key. 0 = disabled; 1 = defrost; 2 = AUX; 3 = economy Setpoint; 4 = Standby; 5 = reset HACCP alarms; 6 = disable HACCP alarms; 7 = Deep Cooling.	0 7	1	1	1	1	num
H32	Configurability of DOWN key. Same as H31.	0 7	0	0	0	0	num
H42	Evaporator probe present. $\mathbf{n}(0) = \text{not present}; \mathbf{y}(1) = \text{present}.$	n/y	у	у	y	у	flag
H43	Probe 3 present. $\mathbf{n}(0) = \text{not present}; \mathbf{y}(1) = \text{present}.$	n/ý	n	ý	n	'n	flag
rEL	Device version. Read-only parameter.	Í	/	1	/	/	1
tAb	tAble of parameters. Reserved: read-only parameter.	/	/	1	/	1	/
	COPY CARD ("FPr" folder)						
UL	Programming parameter transfer from instrument to Copy Card .	/	/	/	/	/	/
Fr	Format Copy Card. Erase all data contained in the Copy Card. NOTE: If parameter "Fr" is used, the data entered will be permanently	/	/	/	/	/	/
	IOST. INIS OPERATION CANNOT DE CANCElled.						
- 4 D	FUNCTIONS ("FIC" tolder)	,					
rAP	Reset pressure switch alarms.		+/-	1		-/	1
rES	Reset HACCP alarms.		/	/	/		

NOTE: If one or more parameters marked with (!) are modified, the controller MUST be switched off and then switched on again to ensure correct operation.



Eliwell Controls s.r.l.

Via dell'Industria, 15 • Z.I. Paludi 32010 Pieve d'Alpago (BL) ITALY T: +39 0437 986 111 F: +39 0437 989 066 www.eliwell.com

Technical Customer Support:

T: +39 0437 986 300 E: Techsuppeliwell@schneider-electric.com

Sales

T:+39 0437 986 100 (Italy) T:+39 0437 986 200 (other countries) E: saleseliwell@schneider-electric.com



code 9IS54157 - IDPlus 902/961/971/974 - EN - rel. 03/16 © Eliwell Controls s.r.l. 2016 • All rights reserved.